



Tape Positioning Dispenser

An innovative tool designed for precise and evenly spaced masking tape application along wall corners and flooring expansion joints—ideal for wall painting and sealant work.

- **Adjustable Distance Rod** Fine-tune the spacing from 0–10mm using the spiral knob to apply masking tape evenly along wall edges for efficient painting or sealant application. (See Fig. 1)
- **Guiding Plate for Flooring Joints** Enables quick and consistent tape placement along flooring expansion joints, streamlining sealant work. (See Fig. 2)
- **Tape Compatibility** Supports tape rolls with inner diameters of Ø26×W15mm and Ø30×W15mm (Ø30 requires adapter ring).
- **Ambidextrous Design** Symmetrical structure allows for left- or right-handed use, with flexible grip options. Flip tape orientation to switch between forward and reverse grip.
- **Built-in Serrated Cutter** Integrated cutting blade at the dispenser head for quick and easy tape tearing.
- **Dual-Color Anti-Slip Body** Soft-textured surface with ergonomic grip for enhanced handling.
- **Dimensions:** W69 × L110 × H30 mm






Fig. 1




Fig. 2

